OPTIMUM OP-2PORTH & OP-MIDH Replacement actuator fitting instructions

- 1. Remove actuator cover.
- 2. Lock lever in "MAN" position.
- 3. Turn valve stem until flat Is parallel as indicated.
- 4. Push actuator onto valve.
- 5. Tighten 2 securing screws.
- 6. Release lever and allow to travel back to "AUTO".



