


ASPIRSIMPLEX AP1180



Installation Instructions

- Read carefully the instructions in this booklet as they give important information on the correct installation, use and maintenance of the appliance. Keep this booklet in a safe place so that it will be available for future reference.
- After unpacking check the integrity of the set. In case of doubt do not use the set and ask for qualified person's intervention. All the packaging (plastic bags, polystyrene foam, nails, etc) must be kept out of the reach of children.
- Before connecting the appliance to the mains supply ensure that the rating label specifications correspond to your electrical supply (The rating label is to be found on the top part of the motor holder).
- This appliance must only be used for the purpose for which it was designed i.e. ventilation of rooms. All other uses must be considered to be potentially dangerous. The Manufacturer cannot be held responsible for any damage caused by improper, incorrect or unreasonable use.
- The safe use of any electrical appliance involves the observing of certain basic rules; in particular:
 - Do not touch the appliance with wet or moist hands or feet. - Do not use the appliance with bare feet.
 - Do not pull the plug from the power socket by the mains lead of the appliance itself.
 - Do not leave the appliance where it is exposed to adverse elements such as rain, salt etc.
 - Do not let young children, aged or infirm people use the device without supervision.
- Before beginning any cleaning or maintenance operations disconnect the appliance from the electrical supply by taking out the plug or switching off the appliance insulation switch.
- In case of a fault and/or malfunction of the appliance, switch it off but do not attempt to rectify. Seek advice from a suitably qualified person. If repair is necessary contact the Manufacturer and ask for only original spare parts. If the above action is not carried out, the safety of the appliance could be jeopardized.
- Should it be decided not to use this appliance any longer, it should be removed from the electrical supply and rendered inoperative, then disposed of in the normal manner. It is also recommended to make harmless those parts of the appliance which could be harmful, especially to children who might play with the disused appliance.
- The installation must conform to the requirements of the latest issue of the I.E.E. wiring regulations.
- This appliance has been constructed to comply with the requirements of the following European Directives CEE 73/23 + CEE 93/68, CEE 89/336 + CEE 93/68.
- The set is workmanlike manufactured. A correct use and a regular maintenance guarantee life and reliability of all electrical and mechanical parts. This appliance is not intended for use by persons (including children) with reduced physical, sensory or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be aware that they do not play with the appliance.

SPECIAL WARNINGS

- Installation must be carried out as detailed in these instructions. The user is warned that incorrect installation could cause harm to persons or animals or damage to property. The Manufacturer cannot be held responsible in such cases.
- The apparatus is double insulated (Class II) and does not require earthing.
- Check that the current carrying capacity of the mains wiring and socket are adequate for the maximum rating of the device shown on the rating label. In case of doubt consult a suitably qualified person.
- When installing, it is necessary to use a double pole switch with a contact separation of 3 mm or more.
- Do not leave the appliance plugged in unnecessarily. Switch off the main switch of the appliance when the appliance is not in use.
- Do not obstruct the air inlet or outlet grilles.
- In conformity with prevention and safety laws in force, when installation of exhaust fan is completed, make sure that it is not at all possible to reach the motion parts from the inlet side. On the contrary it is necessary to mount the special protection shutter (cod. AP0885).
- If there is already a combustion fuel appliance in the room, it is essential to ensure that the air supply to the room is adequate for the correct functioning of both the combustion appliance and the fan. Do not install the fan in the same duct where gas appliance fume is conveyed. The appliance must discharge into a single exhaust pipe or directly outside the building.
- The system can be either wall-mounted or ceiling-mounted.

INSTALLATION AND ELECTRIC CONNECTION (Fig. 1 - 2 - 3 - 4)

- Separate front cover (1) from main fan assembly (2).
- Release with the aid of a small screwdriver blade pressed through side holes (5) (Fig. 2).
- Carefully align the fan assembly (2) to the outlet hole; secure using wall plugs (4) and screws (3) (Fig. 1).
- Insert power cable in housing (Fig. 3) and connect to terminal block (Fig. 4).
- Do not use flat (rip-type) wiring.
- Before fitting the front cover (in the labyrinth cable connection), pull the wiring so that it does not come out of its seat.
- If connecting with outside wiring, break off one of the two plastic parts (E) of the motor support in order to pass the cable (Fig. 2).
- If the input power line is under chase, break off the plastic part (F) of the motor support, in order to pass the wiring (Fig. 3).
- Securely replace front cover (1) to fan assembly (2).

MAINTENANCE: After having disconnected the power supply, using the greatest care, wash every dirty part in water with neutral washing liquid.

NEVER IMMERSE ELECTRICAL PARTS IN WATER OR OTHER LIQUIDS.

OPERATING INSTRUCTIONS FOR MODELS WITH TIMER

On the models with timer the operating time is originally set for about 45 seconds.

Normal operation is ensured also with no bulb or with a burnt out bulb.

The timer switches on the fan when the light is turned on.

When the light is turned off, the fan continues to operate, for the programmable time, from 45 sec. to 30 min.

To prolong the operation time, proceed as follows:

- Disconnect the power supply.
- Turn the trimmer (F) on the timer carefully with a screw-driver in the direction of the arrow (Fig. 5).
- Verify if the operational time has been correctly set, if not repeat following the instructions carefully.
- The installation and the electrical connection are illustrated on Fig. 5.

MODELS WITH PULL-CORD

- The electrical connection is illustrated on Fig. 4. It is only necessary to exclude the one-pole switch (C) as described on the electrical scheme.

Il simbolo del cassonetto barrato riportato sull'apparecchiatura o sulla confezione indica che il prodotto alla fine della propria vita utile deve essere raccolto separatamente dagli altri rifiuti.

L'utente dovrà, pertanto, conferire l'apparecchiatura giunta a fine vita agli idonei centri di raccolta differenziata dei rifiuti elettronici ed elettrotecnici, oppure riconsegnarla al rivenditore al momento dell'acquisto di una nuova apparecchiatura di tipo equivalente in ragione di uno a uno.

L'adeguata raccolta differenziata per l'avvio successivo dell'apparecchiatura dismessa al riciclaggio, al trattamento e allo smaltimento ambientalmente compatibile contribuisce ad evitare possibili effetti negativi sull'ambiente e sulla salute e favorisce il reimpiego e/o riciclo dei materiali di cui è composta l'apparecchiatura.

Lo smaltimento abusivo del prodotto da parte dell'utente comporta l'applicazione delle sanzioni amministrative di cui al D.Lgs n. 22/1997 (articolo 50 e seguenti del D.Lgs. n.22/1997)



Fig./Abb./Afb. 1




Fig./Abb./Afb. 2




Fig./Abb./Afb. 3




Fig./Abb./Afb. 4





Fig./Abb./Afb. 5



A - MORSETTIERA ASPIRTIMER
ASPIRTIMER CLAMPBOARD
BOÎTE A BORNES ASPIRTIMER
ASPIRTIMER KLEMMBRETT
KLEMMENSTRIP VAN ASPIRTIMER
TERMINALER ASPIRTIMER
ΠΙΝΑΚΑΣ ΑΚΡΟΔΕΚΤΩΝ ASPIRTIMER

PRIKLJUCNE STEZALJKE ASPERTIMERA

B - LAMPADA DI ILLUMINAZIONE
BULB
LAMPE
LAMPE
LAMP
PÆRE
LAMPRA ZA OSVJETLJENJE
ΛΑΜΠΑ

C - INTERRUTTORE DI COMANDO
SWITCH
INTERRUPTEUR
SCHALTER
BEDIENINGSSCHAKELAAR
KONTAKT
KOMANDINI PREKIDAC
ΔΙΑΚΟΠΤΗΣ

D - INTERRUTTORE GENERALE
MAIN SWITCH
INTERRUPTEUR GENERAL
HAUPTSCHALTER
HOOFDSCHAKELAAR
HOVEDAFBRYDER
OPCI PREKIDAC
ΓΕΝΙΚΟΣ ΔΙΑΚΟΠΤΗΣ

E - COPERCHIO TIMER
TIMER COVER
COUVERCLE DU TIMER
TIMER DECKEL
DEKSEL VAN DE TIMER
TIMERS LÅGET
ZASTITNA MASKA/POKLOPAC TIMERA
ΚΑΠΑΚΙ TIMER

F - TRIMMER